



# BD-4EA Power Transmitter

Measurement of AC signals 50-60Hz

Single-phase network

3-phase balanced network

3-phase unbalanced network, 3 wires

3-phase unbalanced network, 4 wires

## Operation Manuel

Version:20090228



Shanghai Acrel Ltd.

ADD: No.253 Yulv Road, Madong Industrial Park, Jiading District, Shanghai, China ZIP: 201801

TEL:0086-21-69158338 FAX: 0086-21-69158303

EMAIL:acrel008@vip.163.com WEB: <http://www.acrel.cn>

# Contents

<b>1 General</b>	1
<b>2 Technical parameters</b>	1
<b>3 Installing and wiring</b>	2
3.1 Outline (Unit: mm)	2
3.2 Wiring	2
<b>4 Programming</b>	3
4.1 Explanation of front	3
4.2 Explanation of keys	3
4.3 Read mode	3
4.4 Programming menu	4
4.5 Programming example	4
4.5.1 Set CT ratio (Same as setting PT ratio)	4
4.5.2 Set analog outputs	4
<b>5. Communication</b>	5
5.1 General	5
5.2 Protocol	5
5.2.1 Data frame format	5
5.2.2 Address	5
5.2.3 Function	5
5.2.4 Data	5
5.2.5 Error check	6
5.3 Function code	6
5.3.1 The function code 03H or 04H: Read register	6
5.3.2 The function code 10H: Multi register	6
5.4 Communication application details	7
5.4.1 Logic input and relay output	7
5.4.2 Power parameters and Electric energy	7
5.5 Communication address table	8

## 1. General

BD-4EA programmable power transmitter specializes in measuring the data of all kinds of AC networks. It can be connected with the control equipment in measuring and controlling system. They comply EN 61326:2006 and EN 61010-1:2001.

They are a kind of programmable transmitter. The user can program it by front or PC software. They have many option functions. They can be equipped RS-485 communication Modbus-RTU; or they can output up to 4 analog signals.


They are a kind of analyzer with excellent cost performance, since they regroup the functions of traditional electric transmitter and digital meters. Therefore they are widely being used in kinds of control system, SCADA system and power management system.

## 2. Technical parameters


Technical parameters		Value
Input	Network	Single-phase network; 3-phase balanced network 3-phase unbalanced, 3 wires; 3-phase unbalanced, 4 wires
	Measurable	Ia,Ib,Ic,Ua,Ub,Uc,Uab,Ubc,Uca,F, $\Sigma P$ , Pa,Pb,Pc, $\Sigma Q$ , Qa,Qb,Qc, $\Sigma S$ , Sa,Sb,Sc, $\Sigma PF$ , PFa,PFb,PFc, 4 quadrant energies, multi-rate energies
	Frequency	45 ~ 65Hz
	Voltage	AC 100V, 400V (programmable)
		Overload: 480V (continuous); 800V during 30s
		Consumption: < 0.2VA
Current	Rating: AC 1A, 5A (programmable)	
	Overload: 6A (continuous); 50A during 1s	
	Consumption: < 0.2VA	
Thermal drift	<200ppm	
Transformation ratio		Programmable
Options	Analog output	Up to 4 outputs, 0 ~ 20mA, 4 ~ 20mA programmable
		Load capacity: $\leq 500\Omega$
	Communication	RS485 (Modbus-RTU protocol)
Pulse	2 pulse outputs (open-collector),	
	Pulse constant: 10000, 40000, 160000 imp/kWh	
Precision		0.5 (F: 0.05Hz; kVar: 1)
Power supply		AC/DC 85 ~ 270V; Consumption $\leq 4VA$
Test voltage		2kVAC/min (voltage input / power; between current inputs)
		1.5kVAC/min (outputs / power)
Insulation		input / housing and output / housing >100M $\Omega$
Environment		Work T: -10 $^{\circ}C$ ~ +45 $^{\circ}C$ ; Storage T: -20 $^{\circ}C$ ~ +70 $^{\circ}C$
		Relative humidity: 5% ~ 95% (no condensation)
		Altitude: $\leq 2500m$

### 3. Installing and Wiring

#### 3.1 Outline (Unit: mm)



#### 3.2 Wiring




Note:

1. When the voltage is more than 1.2 times of rated, should use PT; at the voltage input, you should use a 1A fuse
  2. When the current is more than 5A, should use CT;
- Make sure of the correspondance of current input and voltage input, otherwise there will be the error of measure or sign. On the line of CT there are other meters, please make them series  
When out the connection of current input, please cut the CT current input first of all.

## 4. Programming

### 4.1 Explanation of front




When the left LED is of power sign active, it indicates the P/Q/cos in this line is negative.


### 4.2 Explanation of keys

- 1. Click into the programming menu; 2. Return to previous menu
- 1. Choose the menu; 2. Change value
- 1. Enter menu; 2. Valid the value


### 4.3 Read mode




V123: press to switch display phase voltage and line voltage;



I123: display the 3 current;



PQλ: Total P, Q, cos  
press to display the 3 active powers





4 quadrant energies  
EPI (Import kWh);  
EPE (Export kWh)  
EQL (Import kVarh);  
EQC (Export kVarh)  
F: The network frequency

Press, keep and loosen to change the display.  
The left 3 LED are the symbol of value

### 4.4 Programming menu

#### The setting of system

<b>SyS</b>	<b>dISP</b>	<b>0001~0008</b>	Choose start display
	<b>CodE</b>	<b>0001~9999</b>	Set password (default 0001)
	<b>Clr.E</b>		Press  , clear energy
	<b>Clr.d</b>		Press  , clear maximal demand energy
	<b>PL.do</b>	<b>0000~0255</b>	Set relay: 0000 (level mode); 0001-0255 (pulse mode, 0.01s)
	<b>b.Lcd</b>	<b>0000~0255</b>	Set LCD backlight time: 0000 alway ON; 0001-0255 seconds of ON

#### The setting of input

<b>In</b>	<b>LinE</b>	<b>3P4L</b>	Choose networkL: 3-phase 4 wires
		<b>3P3L</b>	3-phase 3 wires
	<b>In.U</b>	<b>100, 400</b>	Choose voltage range: 100V, 400V
	<b>In.I</b>	<b>1, 5</b>	Choose current ranges: 1A, 5A
	<b>In.Pt</b>	<b>0000~9999</b>	Set ratio of PT
	<b>In.Ct</b>	<b>0000~9999</b>	Set ratio of CT

#### The setting of communication

<b>bUS</b>	<b>Addr</b>	<b>0001~0247</b>	Set slave address
	<b>bAUd</b>	<b>4800,9600,19200,38400</b>	Set the speed of communication


#### The setting of analog output (See the "set the analog output")

<b>tr.1</b>	set the 1 <sup>st</sup> analog output
<b>tr.2</b>	set the 2 <sup>nd</sup> analog output
<b>tr.3</b>	set the 3 <sup>rd</sup> analog output
<b>tr.4</b>	set the 4 <sup>th</sup> analog output

When you finish setting, please several  until you see **SAUE** **Yes**, press  to confirm your new setting, and to quit setting please press  until the read mode.


### 4.5 Programming example

#### 4.5.1 Set CT ratio (Same as setting PT ratio)



#### 4.5.2 Set analog outputs

Analog outputs can transmit the 26 measured parameters ( UA, UB, UC, UAB, UBC, UCA, IA, IB, IC, PA, PB, PC, P total, QA, QB, QC, Q total, SA, SB, SC, S total, PFA, PFB, PFC, PF, F ) to isolated DC signal of 0 ~ 20mA or 4 ~ 20mA.



Explanation:

Er.1	<b>1<sup>st</sup> analog output</b>																																																																				
113	<p>The <b>1<sup>st</sup> bit is type of analog</b>, when 0, output 0 ~ 20mA; and when 1, output 4 ~ 20mA. The <b>2<sup>nd</sup> &amp; 3<sup>rd</sup> bit figures the parameter transmitted.</b></p> <table border="1" style="width: 100%; border-collapse: collapse; text-align: center;"> <tr> <td>01</td><td>02</td><td>03</td><td>04</td><td>05</td><td>06</td><td>07</td><td>08</td><td>09</td><td>10</td><td>11</td><td>12</td><td>13</td><td></td> </tr> <tr> <td>Ua</td><td>Ub</td><td>Uc</td><td>Uab</td><td>Ubc</td><td>Uca</td><td>Ia</td><td>Ib</td><td>Ic</td><td>Pa</td><td>Pb</td><td>Pc</td><td>P</td><td></td> </tr> <tr> <td>14</td><td>15</td><td>16</td><td>17</td><td>18</td><td>19</td><td>20</td><td>21</td><td>22</td><td>23</td><td>24</td><td>25</td><td>26</td><td></td> </tr> <tr> <td>Qa</td><td>Qb</td><td>Qc</td><td>Q</td><td>Sa</td><td>Sb</td><td>Sc</td><td>S</td><td>PFa</td><td>PFb</td><td>PFc</td><td>PF</td><td>F</td><td></td> </tr> </table>													01	02	03	04	05	06	07	08	09	10	11	12	13		Ua	Ub	Uc	Uab	Ubc	Uca	Ia	Ib	Ic	Pa	Pb	Pc	P		14	15	16	17	18	19	20	21	22	23	24	25	26		Qa	Qb	Qc	Q	Sa	Sb	Sc	S	PFa	PFb	PFc	PF	F	
01	02	03	04	05	06	07	08	09	10	11	12	13																																																									
Ua	Ub	Uc	Uab	Ubc	Uca	Ia	Ib	Ic	Pa	Pb	Pc	P																																																									
14	15	16	17	18	19	20	21	22	23	24	25	26																																																									
Qa	Qb	Qc	Q	Sa	Sb	Sc	S	PFa	PFb	PFc	PF	F																																																									
6600	<p>The <b>value of 3<sup>rd</sup> line is the maximal value analoged.</b> For example, this 6600kW is corresponding to 20mA of analog output</p>																																																																				

## 5. Communication

### 5.1 General

“9600, 8, n, 1”

9600 is default speed which can also be chosen as 1200, 2400, 4800, 19200 etc. 8 figures 8 bits of data; n figures non- parity; 1 figures 1 stop bit.

Error detection: CRC16 (cyclic redundancy checks)

### 5.2 Protocol

#### 5.2.1 Data frame format

Address	Function	Data	Check
8-Bits	8-Bits	N×8-Bits	16-Bits

#### 5.2.2 Address

The address is at the front of the frame, with one byte (8 bits binary code); Decimal is 0 ~ 255. In our system, only 1 ~ 247 is used, other address is reserved.

#### 5.2.3 Function

The function code tells the function of the analyzer asked.

Hexadecimal code	Meaning	Action
03H	Read/hold register	Get the current binary value from one or multi hold register
04H	Read/input register	Get the current binary value from one or multi input register
10H	multiregister	Put the binary value into multi hold register.

#### 5.2.4 Data

The data includes the data of specified function needed by analyzer or the data measured by analyzer. These data may be value, parameter address or setting. Example: Function domain asks analyzer to read a register, and data domain must indicate the beginning of register red and the sum of data red.

### 5.2.5 Error check

Analyzer use CRC16 mode. It allows that main equipment and slave equipment check the error in the transmission of data. Sometimes when a data is transmitted from equipment to another under the interferences; it maybe changes in the transmission. So the error check can assure that the main equipment or slave equipment don't answer the data changing in order to assure the security, reliability and efficiency of system.

### 5.3 Function code

#### 5.3.1 The function code 03H or 04H: Read register

The user can get the measurement data from this code. There are no data limits in once demand of main, but it can not surpass the range of address.

For example, read 3 data from No. 01 slave Uab, Ubc, Uca. Uab address is 0028H; Ubc address is 0029H; Uca address is 002AH.

Master transmitting		Transmitting information	Slave returning		Return information
address code		01H	address code		01H
function code		03H	function code		03H
Initial address	High byte	00H	byte quantity		06H
	Low byte	28H	register data	High byte	00H
register quantity	High byte	00H		Low byte	00H
	Low byte	03H	register data	High byte	00H
CRC check code	High byte	85H		Low byte	00H
	Low byte	C3H	register data	High byte	00H
				Low byte	00H
			CRC check code	High byte	21H
				Low byte	75H

#### 5.3.2 The function code 10H: Multiregister

Function code 10H permit user to change the value of multiple registers: system parameters, switching output condition etc. The main writes 16 (32 byte) data once.

For example: the NO.01 slave meter with relay output Do1. The statement address of logic input and relay is 0022H. The 9th-12ths bit correspond to DI1-DI4, and the 13th-14th bits correspond to DO1-DO2.

Master transmitting		Transmitting information	Slave return		Return information
Address code		01H	address code		01H
Function code		10H	function code		10H
Initial address	High byte	00H	Initial address	High byte	00H
	Low byte	22H		Low byte	22H
register quantity	High byte	00H	register quantity	High byte	00H
	Low byte	01H		Low byte	01H
Byte quantity		02H	CRC check code	High byte	A1H
0022H data to be written	High byte	10H		Low byte	C3H
	Low byte	00H			
CRC check code	High byte	ADH			
	Low byte	12H			



## 5.4 Communication application details

### 5.4.1 Logic input and relay output

Our logic input is dry contacts with +5V power. When external contacts is NO or NC, our analyzer will display its statement. And it can transmit the statement by RS485 communication.

Its relay output can be controlled by upper monior ( 1. electrical level trigger; 2. pulse trigger ) ; also the user can take it as alarm ( over current, over voltage, under voltage ) .

The address corresponding to address of logic input and relay output is 0022H

0022H	16	15	14	13	12	11	10	9	8 ~ 1
			DO2	DO1	DI4	DI3	DI2	DI1	Reserved

### 5.4.2 Power parameters and Electric energy

The measurement value is read by No.3 command of Modbus-RTU protocol. The corresponding relation between the Communication value and actual value as following:( Val\_tas Communication value, Val\_s as actual value )

**1. Phase voltage UA, UB, UC, line voltage Uab, Ubc, Uca:**

$Val_s = Val_t \times 10^{\wedge} (DPT-4)$  ; Unit: V; DPT high byte reeded from 0023H.

**2. Current Ia, Ib, Ic:**

$Val_s = Val_t \times 10^{\wedge} (DCT-4)$  ;Unit: A; DCT low byte reeded from 0023H.

**3, Power Pa, Pb, Pc, P total, Qa, Qb, Qc, Q total:**

$Val_s = Val_t \times 10^{\wedge} (DPQ-4)$  ; active power Unit: W, reactive power Unit: var; DPQH high byte readed from 0024, Unit of active power and reactive power are readed by 0024H low byte ( from high to low: Q, Qc, Qb, Qa, P, Pc, Pb, Pa ) . .

**4, Power factor value PFA, PFB, PFC, PFS:**

$Val_s = Val_t / 1000$ , no Unit

**5, Frequency:**

$Val_s = Val_t / 100$ , Unit:Hz

**6, Electric energy:**

There are 2 types of reading energies, and the user can choose according to his need.

a) First of all, read secondary energies: 003FH ~ 0040H ( EPI ) , 0041H ~ 0042H ( EPE ) , 0043H ~ 0044H( EQI ) , 0045H ~ 0046H( EQC ) ; then read PT, CT to calculate the primary energies:

$Val_t = \text{First word} \times 65536 + \text{second word}$

The primary value  $Val_s = Val_t / 1000 \times PT \times CT$ . PT slave from 0003H, CT slave from 0004H .

b) Read primary energies in 0047H ~ 004EH, with fomate of float. It figures the sign by sign bit, and figures the size of number by exponent and mantissa. The meters applies IEEE754 with 24 bits precision, the mantissa high bit is always "1", so that it can not be saved:

1 Symbol bit, 8 exponent bits, 23 mantissa bits, symbol bit is the highest bit, and mantissa bit is the lowest bit.

For example: the following number (such as 03FH 040H, 2 bytes, there total 4 bytes from high to low,32 bit)

<u>0</u>	<u>10001110</u>	<u>100 1011 1010 1100 0000 0000</u> b
Symbol bit S	exponent bit E	mantissa M

symbol bit S=0, "1" as negative, "0" as positive;

calculate exponent mantissa E=10001110, change into decimal as 142;

calculate mantissa M=100 1011 1010 1100 0000 0000, change into decimal as 4959232.

Computing formula: **primary energies**

$$= (-1)^S \times 2^{(E-127)} \times \left(1 + \frac{M}{2^{23}}\right) = (-1)^0 \times 2^{(142-127)} \times \left(1 + \frac{4959232}{2^{23}}\right)$$

$$= 52140 \text{ Wh} = 52.14\text{kWh}$$

### 5.5 Communication address table

Address	Parameter	R/W	Value range	Data type
0000H	Enter password	R/W	0001-9999	word
0001H high byte	Communication address	R/W	0001-0247	word
0001H low byte	Communication speed	R/W	0-3; 38400, 19200, 9600, 4800bps	
0002H	Control word	R/W	8 <sup>th</sup> bit Connection mode (0-3P4L, 1-3P3L) 7 <sup>th</sup> bit- voltage range (0-400V, 1-100V ) 2 <sup>nd</sup> bit current range ( 0-5A, 1-1A )	word
0003H	PT ratio	R/W	0001-9999	word
0004H	CT ratio	R/W	0001-9999	word
0005H -000AH	tr.1-tr.4 4 analog outputs	R/W	Each output with 3 bytes ( 1 <sup>st</sup> byte is analog type, 2 <sup>nd</sup> , 3 <sup>rd</sup> byte correspond to full value output )	word
000BH -0010H	Reserved			word
0011H low byte	Set the pulse width of relay output	R/W	Only for it with relay output	word
0023H high byte	Decimal point U (DPT)	R	3 ~ 7	Word
0023H low byte	Decimal point I (DCT)	R	1 ~ 5	
0024H high byte	Decimal point PQ (DPQ)	R	4 ~ 10	Word
0024H low byte	Symbol of P, Q	R	high level - low level: Q, Qc, Qb, Qa, P, Pc, Pb, Pa; 0 as positive, 1 as negative	
0025H	Phase voltage UA	R	0-9999	word
0026H	Phase voltage UB	R	0-9999	word
0027H	Phase voltage UC	R	0-9999	word
0028H	Line voltage UAB	R	0-9999	word
0029H	Line voltage UBC	R	0-9999	word
002AH	Line voltage UAC	R	0-9999	word
002BH	IA	R	0-9999	word
002CH	IB	R	0-9999	word
002DH	IC	R	0-9999	word
002EH	PA	R	0-9999	word

002FH	PB	R	0-9999	word
0030H	PC	R	0-9999	word
0031H	P total	R	0-9999	word
0032H	QA	R	0-9999	word
0033H	QB	R	0-9999	word
0034H	QC	R	0-9999	word
0035H	Q total	R	0-9999	word
0036H	COSA	R	0-1000	word
0037H	COSB	R	0-1000	word
0038H	COSC	R	0-1000	word
0039H	COS total	R	0-1000	word
003AH	SA	R	0-9999	word
003BH	SB	R	0-9999	word
003CH	SC	R	0-9999	word
003DH	S total	R	0-9999	word
003EH	Frequency F	R	4500-6500	word
Address table of energies				
003FH -0040H	Measued import kWh	R/W	0-999999999	Dword
0041H -0042H	Measued export kWh	R/W	0-999999999	Dword
0043H -0044H	Measued import kVarh	R/W	0-999999999	Dword
0045H -0046H	Measued export kVarh	R/W	0-999999999	Dword
0047H -0048H	Real import kWh	R		Fword
0049H -004AH	Real export kWh	R		Fword
004BH -004CH	Real import kVarh	R		Fword
004DH -004EH	Real Export kVarh	R		Fword