

Model Number

NCN8-18GM40-N0

Features

- 8 mm non-flush
- Stainless steel housing •
- Usable up to SIL 2 acc. to IEC 61508

Technical Da	ta		
General specification	ons		
Switching function			Norm
Output type			NAM
Rated operating dis	stance	s _n	8 mm
Installation			non-fl
Assured operating	distance	sa	06
Actual operating di		s _r	7.2
Reduction factor r _A			0.42
Reduction factor rc			0.4
Reduction factor r ₃	04		0.72
Nominal ratings			
Nominal voltage		Uo	8.2 V
Switching frequence	су	f	03
Hysteresis		н	11
Reverse polarity pr			revers
Short-circuit protect			yes
Current consumpti	on		
Measuring plate	not detected		≥ 3 m
Measuring plate	detected		≤ 1 m.
Switching state ind	icator		all dire
Functional safety re	elated paramete	rs	
MTTF _d			2040
Mission Time (T _M)			20 a
Diagnostic Covera	ge (DC)		0 %
Ambient conditions	S		
Ambient temperatu	ire		-25
Storage temperatu			-40
Mechanical specifi	cations		
Connection type			cable
Core cross-section	1		0.75 r
Housing material			Stainl
Sensing face			PBT
Degree of protection	on		IP66 /
Cable			
Bending radius			> 10 >
General information	n		
Use in the hazardo	us area		see in
Category			1G; 2
Compliance with st	tandards and dir	rectives	
Standard conformit			
NAMUR			EN 60
NAMUR			IEC 6
Electronic en electro			NE 21
Electromagnetic	compatibility		NE 2

nally closed (NC) IUR flush 6.48 mm 8.8 mm typ. 8 mm ′ (R_i approx. 1 kΩ) 300 Hz 15 typ. 5 % se polarity protected ۱A ۱A rection LED, yellow a .. 100 °C (-13 ... 212 °F) .. 100 °C (-40 ... 212 °F) e PVC , 2 m mm² less steel 1.4305 / AISI 303 / IP67 x cable diameter nstruction manuals 2G; 3G; 1D; 3D 0947-5-6:2000 60947-5-6:1999 21:2007 EN 60947-5-2:2007 IEC 60947-5-2:2007

Approvals and certificates


Standards

FM approval
Control drawing
UL approval
CSA approval
CCC approval

116-0165 cULus Listed, General Purpose cCSAus Listed, General Purpose CCC approval / marking not required for products rated ${\leq}36$ V

1

Dimensions



Refer to "General Notes Relating to Pepperl+Fuchs Product Information" Pepperl+Fuchs Group www.pepperl-fuchs.com USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com


Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

PEPPERL+FUCHS Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



NCN8-18GM40-N0

Electrical Connection



Refer to "General Notes Relating to Pepperl+Fuchs Product Information".

Pepperl+Fuchs Group USA www.pepperl-fuchs.com fa-info@

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



2

Equipment protection level Ga	
Instruction	Manual electrical apparatus for hazardous areas
Device category 1G EC-Type Examination Certificate	for use in hazardous areas with gas, vapour and mist PTB 00 ATEX 2048 X
CE marking	C € 0102
ATEX marking	(E) II 1G Ex ia IIC T6T1 Ga The Ex-related marking can also be printed on the enclosed label.
Standards	EN 60079-0:2012+A11:2013 EN 60079-11:2012 Ignition protection "Intrinsic safety" Use is restricted to the following stated conditions
Appropriate type	NCN8-18GMN0
Effective internal inductivity C _i	\leq 95 nF ; a cable length of 10 m is considered.
Effective internal inductance Li	\leq 100 μH ; a cable length of 10 m is considered.
General	The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The EU-type examination certificate has to be observed. The special conditions must be adhered to! The ATEX directive and therefore the EU-type examination certificates apply in gen- eral only to the use of electrical apparatus under atmospheric conditions. The use in ambient temperatures of > 60 °C was tested with regard to hot surfaces by the mentioned certification authority. If the equipment is not used under atmospheric conditions, a reduction of the permis- sible minimum ignition energies may have to be taken into consideration.
Ambient temperature	Details of the correlation between the type of circuit connected, the maximum per- missible ambient temperature, the temperature class, and the effective internal reac- tance values can be found on the EC-type examination certificate. <u>Note</u> : Use the temperature table for category 1 !!! The 20 % reduction in accordance with EN 1127- 1 has already been applied to the temperature table for category 1.
Installation, commissioning	Laws and/or regulations and standards governing the use or intended usage goal must be observed. The intrinsic safety is only assured in connection with an appropriate related appara- tus and according to the proof of intrinsic safety. The associated apparatus must satisfy the requirements of category ia. Due to the possible danger of ignition, which can arise due to faults and/or transient currents in the equipotential bonding system, galvanic isolation of the power supply and signal circuit is preferable. Associated apparatus without electrical isolation must only be used if the appropriate requirements of IEC 60079-14 are met. If the Ex- related marking is printed only on the supplied label, then this must be attached in the immediate vicinity of the sensor. The sticking surface for the label must be clean and free from grease. The attached label must be legible and indelible, including in the event of possible chemical corrosion.
Maintenance	No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.
Special conditions	The connecting parts of the sensor must be set up in such a way that degree of pro- tection IP20, in accordance with IEC 60529, is achieved as a minimum.
Protection from mechanical danger	When using the device in a temperature range of -60 °C to -20 °C, protect the sensor against the effects of impact by installing an additional enclosure. The information regarding the minimum ambient temperature for the sensor as provided in the datasheet must also be observed.
Electrostatic charge	Electrostatic charges on the metal housing components must be avoided. Danger- ous electrostatic charges on the metal housing components can be avoided by incor- porating these components in the equipotential bonding.

Refer to "General Notes Relating to Pepperl+Fuchs Product Information"

Pepperl+Fuchs Group www.pepperl-fuchs.com USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

21 776 4411 Singap rl-fuchs.com fa-info@so



Equipment protection level Gb	
Instruction	Manual electrical apparatus for hazardous areas
Device category 2G EC-Type Examination Certificate CE marking	for use in hazardous areas with gas, vapour and mist PTB 00 ATEX 2048 X C \pounds 0102
ATEX marking	(☑) II 1G Ex ia IIC T6T1 Ga The Ex-significant identification is on the enclosed adhesive label
Standards	EN 60079-0:2012+A11:2013 EN 60079-11:2012 Ignition protection "Intrinsic safety" Use is restricted to the following stated conditions
Appropriate type	NCN8-18GMN0
Effective internal inductivity C _i	\leq 95 nF ; a cable length of 10 m is considered.
Effective internal inductance L _i	\leq 100 μH ; a cable length of 10 m is considered.
General	The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The EU-type examination certificate has to be observed. The special conditions must be adhered to! The ATEX directive and therefore the EU-type examination certificates apply in gen- eral only to the use of electrical apparatus under atmospheric conditions. The use in ambient temperatures of > 60 °C was tested with regard to hot surfaces by the mentioned certification authority. If the equipment is not used under atmospheric conditions, a reduction of the permis- sible minimum ignition energies may have to be taken into consideration.
Maximum permissible ambient temperature T _{amb}	Details of the correlation between the type of circuit connected, the maximum per- missible ambient temperature, the temperature class, and the effective internal reac- tance values can be found on the EC-type examination certificate.
Installation, commissioning	Laws and/or regulations and standards governing the use or intended usage goal must be observed. The intrinsic safety is only assured in connection with an appropriate related apparatus and according to the proof of intrinsic safety. If the Ex-related marking is printed only on the supplied label, then this must be attached in the immediate vicinity of the sensor. The sticking surface for the label must be clean and free from grease. The attached label must be legible and indelible, including in the event of possible chemical corrosion.
Maintenance	No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.
Special conditions	The connecting parts of the sensor must be set up in such a way that degree of pro- tection IP20, in accordance with IEC 60529, is achieved as a minimum.
Protection from mechanical danger	When using the device in a temperature range of -60 °C to -20 °C, protect the sensor against the effects of impact by installing an additional enclosure. The information regarding the minimum ambient temperature for the sensor as provided in the datasheet must also be observed.
Electrostatic charge	Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding.

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Inductive sensor

Equipment protection level Gc (nL) Note

Instruction

Device category 3G (nL) CE marking

ATEX marking Standard conformity

Effective internal capacitance C_i Effective internal inductance L_i

General

Installation, commissioning

Maintenance

Special conditions

for Pi=34 mW, Ii=25 mA, T6 for Pi=34 mW, Ii=25 mA, T5 for Pi=34 mW, Ii=25 mA, T4-T1 for Pi=64 mW, Ii=25 mA, T6 for Pi=64 mW, Ii=25 mA, T5 for Pi=64 mW, Ii=25 mA, T4-T1 for Pi=169 mW, Ii=52 mA, T6 for Pi=169 mW, Ii=52 mA, T4-T1 for Pi=242 mW, Ii=76 mA, T6 for Pi=242 mW, Ii=76 mA, T5 for Pi=242 mW, Ii=76 mA, T4-T1

Protection from mechanical danger

Protection from UV light

Protection of the connection cable

Electrostatic charge

Connection parts

This instruction is only valid for products according to EN 60079-15:2005, valid until 01-May-2013

Manual electrical apparatus for hazardous areas

for use in hazardous areas with gas, vapour and mist \mathbf{C}

🐼 II 3G Ex nL IIC T6 X

EN 60079-15:2005 Ignition protection category "n" Use is restricted to the following stated conditions

 \leq 95 nF ; a cable length of 10 m is considered.

 \leq 100 μH ; A cable length of 10 m is considered.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The data stated in the data sheet are restricted by this operating instruction!

The special conditions must be observed!

The ATEX Directive applies only to the use of apparatus under atmospheric conditions.

If you use the device outside atmospheric conditions, consider that the permissible safety parameters should be reduced.

Laws and/or regulations and standards governing the use or intended usage goal must be observed. The sensor must only be operated with an energy-limited circuit, which satisfies the requirements of IEC 60079-15. The explosion group complies with the connected, supplying, power limiting circuit.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

55	°C (131 °F)
55	°C (131 °F)
52	°C (125.6 °F)
52	°C (125.6 °F)
52	°C (125.6 °F)
44	°C (111.2 °F)
44	°C (111.2 °F)
44	°C (111.2 °F)

The sensor must not be exposed to **ANY FORM** of mechanical danger. When used in the temperature range below -20 °C the sensor should be protected from knocks by the provision of an additional housing.

The sensor and the connection cable must be protected from damaging UV-radiation. This can be achieved when the sensor is used in internal areas.

The connection cable must be prevented from being subjected to tension and torsional loading.

Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding.

The connection parts are to be installed, such that a minimum protection class of IP20 is achieved, in accordance with IEC 60529.

Refer to "General Notes Relating to Pepperl+Fuchs Product Information"

Pepperl+Fuchs Group www.pepperl-fuchs.com fa Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com



Equipment protection level Gc (ic)	
Instruction	Manual electrical apparatus for hazardous areas
Device category 3G (ic)	for use in hazardous areas with gas, vapour and mist
Certificate of Compliance	PF 13 CERT 2895 X
CE marking	(€
ATEX marking	⟨ Ex⟩ II 3G Ex ic IIC T6T1 Gc The Ex-significant identification is on the enclosed adhesive label
Standards	EN 60079-0:2012+A11:2013 EN 60079-11:2012 Ignition protection category "ic" Use is restricted to the following stated conditions
Effective internal inductivity C _i	\leq 95 nF ; a cable length of 10 m is considered.
Effective internal inductance L _i	\leq 100 μH ; A cable length of 10 m is considered.
General	The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The data stated in the data sheet are restricted by this operating instruction! The special conditions must be observed! The ATEX Directive applies only to the use of apparatus under atmospheric condi- tions. If you use the device outside atmospheric conditions, consider that the permissible safety parameters should be reduced.
Installation, commissioning	Laws and/or regulations and standards governing the use or intended usage goal must be observed. The sensor must only be operated with energy-limited circuits, which satisfy the requirements of IEC 60079-11. The explosion group complies with the connected, supplying, power limiting circuit. If the Ex-relevant identification is printed exclusively on the adhesive label provided, this label must be affixed in the immediate vicinity of the sensor! The background surface to which the adhesivelabel is to be applied must be clean and free from grease! The applied label must be dura- ble and remain legible, with due consideration of the possibility of chemical corro- sion!
Maintenance	No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.
Special conditions	
for Pi=34 mW, li=25 mA, T6	55 °C (131 °F)
for Pi=34 mW, li=25 mA, T5	55 °C (131 °F)
for Pi=34 mW, li=25 mA, T4-T1	55 °C (131 °F)
for Pi=64 mW, li=25 mA, T6	55 °C (131 °F)
for Pi=64 mW, li=25 mA, T5	55 °C (131 °F)
for Pi=64 mW, li=25 mA, T4-T1	55 °C (131 °F)
for Pi=169 mW, li=52 mA, T6	52 °C (125.6 °F)
for Pi=169 mW, li=52 mA, T5	52 °C (125.6 °F)
for Pi=169 mW, li=52 mA, T4-T1	52 °C (125.6 °F)
for Pi=242 mW, li=76 mA, T6	44 °C (111.2 °F)
for Pi=242 mW, li=76 mA, T5	44 °C (111.2 °F)
for Pi=242 mW, li=76 mA, T4-T1	44 °C (111.2 °F)
Protection from mechanical danger	The sensor must not be mechanically damaged.

Electrostatic charge

Connection parts

When used in the temperature range below -20 °C the sensor should be protected from knocks by the provision of an additional housing.

Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding.

The connection parts are to be installed, such that a minimum protection class of IP20 is achieved, in accordance with IEC 60529.

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com



Equipment protection level Da	
Instruction	Manual electrical apparatus for hazardous areas
Device category 1D	for use in hazardous areas with combustible dust
EC-Type Examination Certificate	PTB 00 ATEX 2048 X
CE marking	€0102
ATEX marking	$\overleftarrow{\mbox{\sc bs}}$ II 1D Ex ia IIIC T135°C Da The Ex-related marking can also be printed on the enclosed label.
Standards	EN 60079-0:2012+A11:2013 EN 60079-11:2012 Ignition protection "Intrinsic safety" Use is restricted to the following stated conditions
Appropriate type	NCN8-18GMN0
Effective internal inductivity C _i	\leq 95 nF ; a cable length of 10 m is considered.
Effective internal inductance L _i	\leq 100 μH ; a cable length of 10 m is considered.
General	The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The EU-type examination certificate has to be observed. The ATEX directive and therefore the EU-type examination certificates apply in gen- eral only to the use of electrical apparatus under atmospheric conditions. The use in ambient temperatures of > 60 °C was tested with regard to hot surfaces by the mentioned certification authority. If the equipment is not used under atmospheric conditions, a reduction of the permis- sible minimum ignition energies may have to be taken into consideration.
Maximum permissible ambient temperature T_{amb}	Details of the correlation between the type of circuit connected, the maximum per- missible ambient temperature, the surface temperature, and the effective internal reactance values can be found on the EC-type-examination certificate. The maximum permissible ambient temperature of the data sheet must be noted, in addition, the lower of the two values must be maintained.
Installation, commissioning	Laws and/or regulations and standards governing the use or intended usage goal must be observed. The intrinsic safety is only assured in connection with an appropriate related appara- tus and according to the proof of intrinsic safety. If the Ex-related marking is printed only on the supplied label, then this must be attached in the immediate vicinity of the sensor. The sticking surface for the label must be clean and free from grease. The attached label must be legible and indeli- ble, including in the event of possible chemical corrosion.
Maintenance	No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.
Special conditions	The connecting parts of the sensor must be set up in such a way that degree of pro- tection IP20, in accordance with IEC 60529, is achieved as a minimum.
Protection from mechanical danger	When using the device in a temperature range of -60 °C to -20 °C, protect the sensor against the effects of impact by installing an additional enclosure. The information regarding the minimum ambient temperature for the sensor as provided in the datasheet must also be observed.
Electrostatic charge	Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding. Do not attech the namedicto provided in arrow where electrostatic charge can build

Do not attach the nameplate provided in areas where electrostatic charge can build up.

Refer to "General Notes Relating to Pepperl+Fuchs Product Information".

Pepperl+Fuchs Group www.pepperl-fuchs.com Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com



NCN8-18GM40-N0

Equipment protection level Dc (tc)

Instruction

Device category 3D Certificate of Compliance CE marking

ATEX marking

Standards

General

Installation, commissioning

Maintenance

Special conditions

Minimum series resistance R_V

Maximum operating voltage UBmax

Maximum permissible ambient temperature T_{Umax}

at U_{Bmax}=9 V, R_V=562 Ω using an amplifier in accordance with EN 60947-5-6 Protection from mechanical danger Protection from UV light

Protection of the connection cable

Electrostatic charge

Manual electrical apparatus for hazardous areas

for use in hazardous areas with combustible dust PF 15CERT3774 X €0102

↔ II 3D Ex tc IIIC T80°C Dc The Ex-related marking can also be printed on the enclosed label.

EN 60079-0:2012+A11:2013, EN 60079-31:2014

Protection by enclosure "tc" Some of the information in this instruction manual is more specific than the information provided in the datasheet.

The corresponding datasheets, declarations of conformity, EC-type examination certificates, certifications, and control drawings, where applicable (see datasheets), form an integral part of this document. These documents can be found at www.pepperl-

luchs.com. The maximum surface temperature of the device was determined without a layer of dust on the apparatus. Some of the information in this instruction manual is more specific than the information provided in the datasheet.

Laws and/or regulations and standards governing the use or intended usage goal must be observed. If the Ex-relevant identification is printed exclusively on the adhesive label provided, this label must be affixed in the immediate vicinity of the sensor! The background surface to which the adhesivelabel is to be applied must be clean and free from grease! The applied label must be durable and remain legible, with due consideration of the possibility of chemical corrosion!

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

A minimum series resistance RV is to be provided between the power supply voltage and the proximity switch in accordance with the following list. This can also be assured by using a switch amplifier.

The maximum permissible operating voltage UBmax must be restricted to the values given in the following list. Tolerances are not permitted.

Values can be obtained from the following list, depending on the max. operating voltage Ub max and the minimum series resistance Rv.

61 °C (141.8 °F) 61 °C (141.8 °F)

The sensor must not be exposed to ANY FORM of mechanical danger.

The sensor and the connection cable must be protected from damaging UV-radiation. This can be achieved when the sensor is used in internal areas.

The connection cable must be prevented from being subjected to tension and torsional loading.

Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding. Do not attach the nameplate provided in areas where electrostatic charge can build up.

PEPPERL+FUCHS

fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com